

AA Tuning E36 Track Pipe

Installation Instructions

Tools Needed:

- 12 mm wrench
- 13 mm socket
- 13 mm wrench
- 14 mm wrench or socket
- 15 mm socket
- WD-40 or similar lubricant

WARNING: Do not use air tools on manifold nuts. Vibration will damage O2 sensors.

1. Place car on lift and spray manifold nuts and rear muffler pipe bolt with WD-40.
2. Disconnect O2 sensor behind catalyst. Use a 12mm or 13mm socket or wrench to pull joint between rear muffler and catalyst.
3. Pull the six 15mm bolts holding down pipe to manifold. With someone holding up muffler system, or support stand in place, pull off rubber mounts. Remove system.
4. Fit new Track Pipe headers to manifold making sure gaskets are in place. Tighten bolts.
5. Tighten all bolts and replace rubber hangers.
6. Plug on new simulators and tie strap to fuel lines (OBD2 CARS ONLY)

AA TRACK PIPE SYSTEM IS DESIGNED FOR OFF ROAD USE AND RACING APPLICATION ONLY.